


Versuchs- und Lehranstalt für Brauerei in Berlin (VLB) e.V.

Production methods for alcohol-free Beer (NAB)- an overview

Any unauthorized use, such as distributing, copying, changing or reprinting, is not permitted




Topic worldwide




Overview different procedures




brewhouse



fermentation




filtration



De-aeration

Overview different procedures



Immature & warty character
sweet

fermentation

Overview different procedures

Low in light volatiles/ empty oxidized – thermal
Slightly acidic- Membrane




De-alcoholization

Overview different procedures



brewhouse



fermentation

&



De-alcoholization



Brewhouse possibilities



VLB
BERLIN

Overview different procedures in the brewhouse

Differentiation between

1. Wort for dealcoholization
2. Wort of „incomplete“ fermentation
3. Wort for “Aroma“ beer for blending

Process parameters:

- Use of special malts
- Mashing procedure: low fermentation degree
- Hop dosage
- Original gravity
- pH-optimization




brewhouse

Overview different procedures in the brewhouse

Mashing procedure: low fermentation degree

- “Jump” mashing process ~ 50% ADF
- single step infusion around 72-74°C ~ 60% ADF
- Original gravity: 8 - 9 °P

Jump- mashing procedure



single step infusion mashing





Biological methods during fermentation




VLB
BERLIN

Overview different procedures during fermentation

Complete fermentation

1. Beer for dealcoholization
2. "Aroma" beer for blending



fermentation

Incomplete Fermentation

1. Interrupted fermentation
2. Cold contact procedure
3. Use of maltose- negative Yeast

Interruption of fermentation at

fermentation degree of app. 10 % → alcohol < 0,5 vol.%

- OG 7 to 8 °Plato and Mashing procedure: shortened β -amylase rests to build less fermentable sugars
- Acidification of cast wort to beer-pH
- Fermentation at 5 to max. 8 °C (24 to 72 hours)
- To achieve interruption yeast count should be 0,1 mill. cells / mL using: separator, filter, pasteurizer
- Maturation at 0 °C
- Filtration and stabilization with silica gel and PVPP
- **Pasteurization needed**

Pitching temperature at -2 to max. 0°C

Well mixing of yeast and wort

- Low OG 6-8 % and pH- adjustment
- No aeration is necessary; oxygen-poor wort
- Cold contact for 24 to 48 hours
- Ethanol production < 0,1 vol.% !!!!
- **Pasteurization needed**


Yeast is not able to ferment maltose

Significant decrease in wort flavour compounds

- Glucose, fructose or saccharose is assimilated
- Adjusting pH-value to beer pH is necessary
- Low alcohol formation (up 0,5- 1,0% ABV)
- **Pasteurization needed**



Saccharomyces ludwigii



Saccharomyces rosei




De-alcoholization



VLB
BERLIN


Dealcoholization

1. Thermal procedures
2. Membrane based procedures: Dialysis/ reverse osmosis




Dealcoholization

Membran-based – Reverse Osmose




Osmosis



Reverse Osmosis


Membran-based – Reverse Osmose



Beer de-alcoholisation

Dialysis


- + Hollow fibre membranes / modules
- + Diffusion take place by mass transfer by concentration gradient (no pressure difference)
- + Counter current flow
- + Operation pressure 0.5 ± 0.1 bar (beer side)
- + Operation temperature $1\text{ }^{\circ}\text{C}$ to max. $6\text{ }^{\circ}\text{C}$ (cooling)



- General Aspects -

- + Stripping vs. Distillation
- + Applying vacuum distillation (0,04 to 0,2 bar absolute) at 30-60°C
→ avoiding thermal impact
- + Moderate heat transfer rate, depending on “degree of de-alcoholization”
(production of alcohol-reduced beers or alcohol-free beers)
- + Also evaporation of aroma components (HAA, esters)
- + Because of heat input removal of CO₂ → carbonization required


Thermal Beer Dealcoholization Procedures




Take a way




brewhouse



fermentation



filtration



De-aeration




Product- safety



VLB
BERLIN

Product- safety- „normal beer“



CO₂

ABV


pH

hops

boil

Figure 1. Pathogens cannot survive in beer owing to the antimicrobial ‘hurdles’, including the kettle boil, hop bitter acids, low pH, ethanol, carbon dioxide (CO₂) and the lack of nutrients and oxygen (depicted by the wasteland). Artwork by Ms Peggy Hsu. Reproduced with permission from Elsevier (5).

Product- safety- NAB



°P

CO₂

pH

hops

boil


Microbiological
spoilage
Yeast
Bacteria

Changes over time
CO₂
ABV

Thank you for your attention!

VLB Berlin FI Bier- und Getränkeproduktion

Jan Biering
biering@vlb-berlin.org
www.vlb-berlin.org



„Any unauthorized use, such as distributing, copying, changing or reprinting, is not permitted “